

Funktionsumfang der Bedienteile

Info-Hotline: 061 - 7439222

RC V3 (*)

b = 19" (482 mm)
h = 2 HE (88 mm)
t = 42 mm



RCP-1001

b = 19" (482 mm)
h = 2 HE (88 mm)
t = 70 mm



RCP-2001-A

b = 19" (482 mm)
h = 3 HE (132 mm)
t = 70 mm



RCP-2001-B

b = 19" (482 mm)
h = 3 HE (132 mm)
t = 70 mm



Bedienelemente:

LCD-Displays	2x			
VFD-Displays		2x	2x	2x
Jog-Wheels		2x	2x	2x
Pitch-Slider	2x	2x	2x	
Pitch-Wheel				2x
Pitch Bend Tasten	2x	2x	2x	2x
Track-Tasten	2x	(über Jog Wheel)		
Search-Tasten	2x	(über Jog Wheel)		
Cue-Taste, Play-Taste	2x	2x	2x	2x
Cue-Play Taste	2x		2x	2x
BPM Match Taste	2x	2x	2x	2x
Universaltasten A, B, C	2x			
Manual Fader	1x			
Sample Block 1 bis 9	1x		1x	1x
Autofade on/off Taste			1x	1x
Start Fade Taste			1x	1x
Fade Mode Selector			1x	1x
Track Selector / Push Load		2x	2x	2x
Load Taste		2x	2x	2x
Direct-Cue Tasten 1 - 6, Memory			2x	2x
Master Tempo on/off Taste			2x	2x
Pitch on/off Taste		2x	2x	2x
Brake Taste			2x	2x
Pitch Reset Taste				2x
Archiv + Playlist Tasten		2x	2x	2x
Next Track Taste			2x	2x
Time Elapsed/Remain Taste	2x	2x	2x	2x
Mode + Set Tasten		2x	2x	2x
Loop Sampler A , B EXIT Tasten			2x	2x

(*) - Auslaufmodell, nur solange Vorrat reicht

(w) - wahlweise

Änderungen und Irrtümer vorbehalten.

Funktionen:

	RC V3	RCP-1001	RCP-2001-A	RCP-2001-B
6x Direct Cue			2x	2x
Sample Player	yes		yes	yes
Direktzugriff File- /Playlist Archive		yes	yes	yes
Direktauswahl aus den Playlisten		yes	yes	yes
Next-Track Speicher			yes	yes
Search-Funktion	yes	(über Jog Wheel)		
Preview-Player Steuerung			yes	yes
Loop Sampler			yes	yes
Fade Control			yes	yes
Time Elapsed/Remain/Total Anzeige		yes	yes	yes
Brake (Abbremsen und Anfahren)			yes	yes
Digi Scratch (Jog Wheel)		yes	yes	yes
Instant-Cue	yes	yes	yes	yes
BPM Matching	yes	yes	yes	yes
Fader Start	yes	yes	yes	yes

Display:

	RC V3	RCP-1001	RCP-2001-A	RCP-2001-B
Pitch-Wert / BPM-Wert	w	yes / BPM Realtime		
Pitch-Bereich	yes	yes		
Track Nummer	yes	yes		
Next Track Nummer		yes		
Spielzeit Elapsed/Remain	w	w		
Play Position	yes	yes		
Titel / Artist	yes	w		
Gruppen-/ List Name		w		
Ressourcen-Anzeige	yes			
Pegelanzeige	yes			
Pitch/Master Tempo on/off	yes	yes		
Jog Wheel Modus		yes		
Single-/ Cont. Play		yes		
Shuffle on/off		yes		
Repeat on/off		yes		
Loop Play / Record		yes		